


Fötter

	Extr	eme :	Sports	
	Activity	y level		
1	2	3	4	


	Size	Hight	Weight
	(cm)	(mm)	(g)
Freestyle Swim	22 - 25 26 - 28 29 -31	102 107 117	680 790 945

Product weight includes foot shell. Measurements are approximate and will vary due to category selection and manufacturing.

Foot Module Part Number



Foot Shell Part Number



See the Cosmetic Foot Shell page for more detailed ordering instructions.

Freestyle Swim

Walk & Swim – It's Push Button Easy.

Go from walking to swimming with the simple push of a button on the Freestyle Swim Foot. A single adjustment moves the ankle from a 1 cm heel height setting for walking to 70° plantar flexion for swimming. No tools required! Used in conjunction with the LP Symes Prosthetic Foot, the product is sold with a cosmetic foot shell to protect the system. A protective rubber cap is snapped over the ankle for further protection from the elements.

Features

- Users can now walk proudly and comfortably to and from the swim area
- Adjust to 70° plantar flexion for swimming with the simple push of a button
- Utilize a flipper to gain swimming speed and decrease energy expenditure
- Balance the body and enhance swimming efficiency

Specs

- Sizes: 22-30 cm
- User Weight Rating: 116 kg
- Stiffness Categories: 1-6
- Connector: Integral male pyramid
- Heel Height: 10 mm
- Warranty: Ankle 12-month warranty; carbon fiber foot module 36 months

	Weight (kg)		
Low	Moderate	High	
1	1	2	44 - 52
1	2	3	53 - 59
2	3	4	60 - 68
3	4	5	69 -77
4	5	6	78 - 88
5	6		89 - 100
6			101 - 116